

ATrack Active RFID Reader and Tag Installation

Plug the RFID reader into the AK11 using the given wire. Extensions can be made to the wire if required.

For wire extension, please use same diameter wiring. Solder wires together, individually shrink each wire as well as the outside. It is not recommended to use connectors.

Place the RFID reader such that it is within line of sight of would-be RFID tags. Recommended locations include: The dashboard, front or back window.

